

メーカー	型番	BD	DVD	3D	BD-LIVE	BD-ROM
TOSHIBA	DBP-S100	○	○		○	○
	SD-300J		○			
	RD-XS33		○			
Panasonic	DMR-BXT3000	○	○	○	-	-
	DMP-BDT110	○	○	○	○	○
	DMP-BDT900	○	○	○	○	○
	DMR-E80H		○			
SONY	BDP-S190	○	○		○	○
	DVP-NS53P		○			
	DVP-NS700H		○			
SHARP	BD-HP21	○	○		○	
	DV-SF80P		○			
Pioneer	BDP-LX71	○	○		×	○
	BDP-330	○	○		○	
	DV-310		○			
MITSUBISHI	DVR-BZ130	○	○			○
	DVR-HE10W		○			
HP	BD-2000	○	○		○	○
Victor	XV-BP1	○	○			○
	XV-P323		○			
marantz	BD7004	○	○		○	○
LG	LG BP120	○	○			○
GREEN HOUSE	GHV-BD100K	○	○		○	○
oppo	BDP-80	○	○		○	○
YAMAHA	DVD-S657		○			
PlayStation 2	SCPH-37000		○			
	SCPH-90000		○			
PlayStation 3	CECHA00	○	○	○	○	
	CECH-3000A	○	○	○	○	
	CECH-4000B	○	○	○	○	
PlayStation 4	CUHJ-10000	○	○		○	○
Corel	WinDVD Pro 11	○	○	○	○	○
InterVideo	WinDVD 7	○				
CyberLink	PowerDVD 13	○	○	○	○	○
Apple	DVDプレーヤー 5500.48	○				

※所持機種 117機種中、35機種抜粋

2014/4/1